

## NOTES:

- 1. THE WIDTH OF THE FULL DEPTH PATCH OVER A TRENCH SHALL BE 12 (300) WIDER ON EACH SIDE OF THE TRENCH.
- 2. FOR METHOD OF MEASUREMENT AND BASIS OF PAYMENT, SEE RECURRING SPECIAL PROVISION "PATCHING WITH HOT-MIX ASPHALT OVERLAY REMOVAL".

## SEQUENCE OF CONSTRUCTION

- 1. REMOVE THE EXISTING HMA MATERIAL OVER THE AREA TO BE PATCHED.
- 2. REMOVE AND REPLACE FULL DEPTH PATCHES
- 3. REPLACE HMA MATERIAL OVER THE AREA TO BE PATCHED.

ALL DIMENSIONS ARE IN INCHES (MILLIMETERS) UNLESS

REVISIONS		ILLINOIS DEPARTMENT	OF TRANSPORTATIO	NI.
NAME	DATE	TELINOIS DEPARTMENT	OF TRANSPORTATIO	ж
R. SHAH	10/25/94			
R. SHAH	01/14/95			
R. SHAH	03/23/95	PAVEMENT P.	ATCHING FOR	
R. SHAH	04/24/95		IRFACED	
A. HOUSEH	03/15/96			
A. ABBAS	03/21/97	PAVE	MENT	
A. ABBAS	01/20/98			
ART ABBAS	04/27/98	VERT.		

01/01/07 9/04/07 PLOT DATE: 3/31/2008

CHECKED BY BD400-04 (BD-22)

REVISION DATE: 01/01/01